



NTP Test Report



NTP:

Test	NTP in AS200/28/XF v139318
Test procedure	
configuration	<pre> Switch 1: Switch_config# interface VLAN1 // Vlan1 is Created Switch_config# ip address 1.1.1.1 255.255.0.0 //IP addressed is assigned Switch_config# exit Switch_config# ntp master primary //set as server Switch 2: Switch_config# interface VLAN1 //To interface vlan1 Switch_config# ip address 1.1.1.2 255.255.0.0 //assinging IP address Switch_config#exit Switch_config# ntp server 1.1.1.1 //Giving server ip Switch_config #ntp client enable //set as client </pre>
test result	NTP Server:

	<p>NTP Client:</p>
<p>Remarks</p>	<p>The switch can be used as NTP server and NTP client.</p>