




**Alpha Bridge
SYSLOGS in
AS300/56/XC**



Test	SYSLOGS in AS300/56/XC
Test procedure	
configuration	<p>Configuration in AS356XC:</p> <p>syslog server 192.168.200.244 // to set syslog server</p> <p>logging on // to enable logging</p> <p>logging logfile size kbytes 4096 //to keep buffer size</p> <p>logging source all action syslog all level information // to set severity level</p>
test result	<p>Results for SYSLOGS</p> <p>logs in server</p>  <p>To check the logs in Switch.</p>

	<p>Show logbuffer</p> <pre> AS356XC# AS356XC# AS356XC# AS356XC# AS356XC# AS356XC# AS356XC# AS356XC# AS356XC#show logbuffer 2000/01/07 07:38:00.071 AS356XC M01-6-CLI-CHD(1):show logbuffer .[Host=Console User=] 2000/01/07 07:38:00.071 AS356XC M01-6-CLI-CHD(1):show logbuffer .[Host=Console Vtycon User= Prev_node=3 Index_node=3 Result=OK(0)] 2000/01/07 07:35:04.408 AS356XC M01-3-DEVICE-LASER(1):The optical module on interface 10GigabitEthernet1/0/4 is plugged IN. 2000/01/07 07:35:04.408 AS356XC M01-5-DEVICE-INFO(1):Identifiable laser module on 10GigabitEthernet1/0/4,identifier = 0x3 transceiver = 0x1000 type = 3. 2000/01/07 07:35:00.629 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 10.110.255.43 error. 2000/01/07 07:35:00.628 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:35:00.628 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:33:41.556 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 10.110.255.43 error. 2000/01/07 07:33:41.555 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:33:41.555 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:33:41.555 AS356XC M01-3-DEVICE-LASER(1):The optical module on interface 10GigabitEthernet1/0/4 is plugged OUT. 2000/01/07 07:27:40.556 AS356XC M01-6-CLI-CHD(1):logging logfile size kbytes 4096 .[Host=Console User=] 2000/01/07 07:27:40.556 AS356XC M01-6-CLI-CHD(1):logging logfile size kbytes 4096 .[Host=Console Vtycon User= Prev_node=4 Index_node=4 Result=OK(0)] 2000/01/07 07:27:24.622 AS356XC M01-6-CLI-CHD(1):configure .[Host=Console Vtycon User= Prev_node=3 Index_node=4 Result=OK(0)] 2000/01/07 07:26:47.238 AS356XC M01-6-CLI-CHD(1):configure .[Host=Console User=] 2000/01/07 07:26:47.238 AS356XC M01-6-CLI-CHD(1):configure .[Host=Console Vtycon User= Prev_node=3 Index_node=4 Result=OK(0)] 2000/01/07 07:26:12.787 AS356XC M01-6-CLI-CHD(1):show running-config .[Host=Console User=] 2000/01/07 07:26:12.787 AS356XC M01-6-CLI-CHD(1):show running-config .[Host=Console Vtycon User= Prev_node=4 Index_node=4 Result=OK(0)] 2000/01/07 07:25:16.886 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 10.110.255.43 error. 2000/01/07 07:25:16.886 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:25:16.885 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:25:16.883 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 10.110.255.43 error. 2000/01/07 07:25:16.878 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. 2000/01/07 07:25:16.878 AS356XC M01-7-SNMP-TRAP(1):Send SNMP Trap packet to 192.168.200.250 error. --More-- </pre>
Remarks	Switch sends the logs to Syslog server.